

# Rope Maintenance

The ropes on ForPark products are made from a combination of abrasion resistant fibres, braided around a galvanized steel wire core.

Whilst the ropes themselves will require no maintenance (unless subject to vandalism), the plastic connectors should be checked on a regular basis to ensure that they are secure.

The 'standard connector' is used to hold intersecting ropes.

Connectors are fastened over the ropes by being squeezed together and held in place using a self-locking system. They are then secured by use of screws inserted into the rope itself.

The 'standard connector' fits together in two halves.

Rope Net Standard Connector (Part # 57882)

Tool – Standard T20 Torx Drive



For the most current version, please visit:

[www.forpark.com.au/technical/maintenance-and-spare-parts](http://www.forpark.com.au/technical/maintenance-and-spare-parts)